

# **PEEL AWAY<sup>®</sup>**

## **PAINT REMOVAL SYSTEM**

### **How to perform a Trial Patch**

- 1. Always perform a Trial Patch Evaluation prior to every job!**  
Due to many different types of paint and surface conditions, it is important that the correct variables are discovered prior to completing a paint removal project. Peel Away 1 and 8 are available in 350g Trial Kits for this purpose. Kits can be purchased direct from Peel Away or through our Stockists and Distributors throughout Australia.
- 2. Apply the Peel Away paste 3-4mm thick (average rate) directly to the painted surface, creating an even application. Brick and stone work will require you to use the Peel Away paste to fill gaps and mortar to ensure an even coverage.**
- 3. Cover the Peel Away paste with the supplied special Peel Away laminated paper sheet. You may cut this sheet into multiple sections to allow for a 2<sup>nd</sup> patch to be applied on the painted surface. Make sure to gently smooth the paper out, removing any pockets of air trapped under as best you can.**
- 4. Tape down the edges of the paper to the substrate with high stick masking tape.**
- 5. Leave on the surface for 72 hours.**  
(Successful patches can take up to 4-7 days. If unsure how long to leave your patch on, please call our Technical Consultants for advice)
- 6. Slide the spatula behind the paper, and ease the paint, paste and paper off in one piece. Scrape off loose debris and residue and place in thick plastic tie up bags.**
- 7. Thoroughly wash the surface with plain water, nylon brush and sponge.**
- 8. Examine results of Trial Patch and if successful, you have the correct variables to complete the job.**

\*If not successful, leave the 2<sup>nd</sup> Trial Patch intact on the surface and allow more time prior to removing. For timber and painted fibreglass, please contact our Technical Consultants prior to performing this evaluation.

**Technical:**

Care is taken in preparation of this information. Recommendation of technical advice, verbal or trials is given with no responsibility or warranty. Every type of timber / wood product reacts differently and trial evaluations are essential.

Bldcare Australia Pty Ltd ABN 87 003 914 038

**PEEL AWAY** Australia –Asia Pacific Pty Ltd

Homebush Business Village Unit 43, 11-21 Underwood Road Homebush NSW 2140

W: [www.peelaway.com.au](http://www.peelaway.com.au) E: [sales@peelaway.com.au](mailto:sales@peelaway.com.au) P: 02 9746 6733 F: 02 9746 5322

VIC: 1800 033 431 QLD: 07 3260 5727 SA: 08 8344 1153 WA: 08 9362 4744 TAS: 03 6231 9900

Peel Away® is licensed to Bldcare Australia Pty Ltd

Trial Patch 3-4mm thick of Peel Away Paste,  
Covered with paper and taped down to the  
Substrate



Trial Patch removed



Surface washed and cleaned



Results

